

Analytical MicroLabs

Industrial Microbiologists

NATA Accredited Laboratory: 14917

Douglas Hocking Research Institute, The Geelong Hospital, Barwon Health, Ryrie St. Geelong, VIC. 3220
 Phone: 1300 724 961 Fax: 03- 52603183 ABN 55 167 987 554


Citrofresh 14P Propionibacterium acne cream and gel shelf life testing

Certificate number: AML 010705
Batch number: Citrofresh 3603
Date: 28th of June, 2005- 28th of December, 2005
 Accelerated shelf life testing: from 1st of August

Organism tested: 1. Propionibacterium acne ACM 5109

Shelf life in weeks	2 nd week	3 rd week	5 th week	22 nd week	52 th week 1 year	88 th week 1.5 years	104 th week 2 years
“Simply scentual” unscented cream							
0% Citrofresh	No growth	No growth	No growth	No growth	No growth		
5% Citrofresh	No growth	No growth	No growth	No growth	No growth		
10% Citrofresh	No growth	No growth	No growth	No growth	No growth		
“Simply scentual” Aloe Vera gel							
0% Citrofresh	Growth	Growth	Growth	Growth	Growth		
5% Citrofresh	No growth	No growth	No growth	No growth	No growth		
10% Citrofresh	No growth	No growth	No growth	No growth	No growth		

"Simply scentual" unscented gel							
0% Citrofresh	Growth	Growth	Growth	Growth	Growth		
5% Citrofresh	No growth	No growth	No growth	No growth	No growth		
10% Citrofresh	No growth	No growth	No growth	No growth	No growth		

Media and conditions:**Plate Count agar with 100 ul of sample.****Plates are incubated at 35 degree Celsius for 72 hours****Note:****From the 3rd week, accelerated shelf life testing has been introduced.****Samples are incubated at 37.7 degree Celsius incubator****In accelerated shelf life testing, one week is equal to 8.5 weeks normal condition, or 6 weeks is equal to 1 year.**

Zoltan Nack MSc. MBA. MASM**Biologist, Senior Scientist, Analytical MicroLabs**